

Tresor / Safe

In jedem Zimmer steht ein Tresor für Ihre Wertsachen bereit.
In each room there is a safe for personal valuables.

Bedienungsanleitung für den Tresor

Persönlichen Code programmieren

- rote Taste auf der Türinnenseite (hinten) drücken
- ein oranges Licht leuchtet auf
- neuen Geheimcode mit 3 – 8 Stellen innert 10 Sekunden eingeben
- Taste # drücken um den Code zu speichern
- Drehgriff auf der linken Seite der Tastatur innert 5 Sekunden gegen den Uhrzeigersinn bis zum Anschlag drehen
- der Tresor ist nun geschlossen

Tresor öffnen

- Geheimcode eingeben und mit der Taste # bestätigen
- ein grünes Licht leuchtet auf
- Drehgriff auf der linken Seite neben der Tastatur innert 5 Sekunden im Uhrzeigersinn bis zum Anschlag drehen
- der Tresor ist nun offen

Safe Instruction

Program your personal code

- *press the red button on the inside (behind) of the door*
- *an orange light comes on*
- *enter your personal code (3 to 8 numbers)*
- *press the # button to confirm*
- *twist the turning handle in a counterclockwise direction as far as it will go within 5 seconds*
- *the safe is closed now*

Open the safe

- *enter your personal code and confirm with the # button*
- *a green light comes on*
- *twist the turning handle in a clockwise direction as far as it will go within 5 seconds*
- *the safe is open now*

For personal reasons we go to your room once a day.